

Installation of NSK Linear Guides[™]





NSK Linear Guides™: Handling Precautions

NSK linear guides are high quality and easy to use. NSK places importance on safety in design. For maximum safety, please follow precautions as outlined below.

(1) Lubrication



- a. If anti-corrosive oil has been applied, thoroughly wipe the rust prevention oil and put lubricant inside slide before using. For seal lubrication products, put lubricant on the rail.
- b. Do not mix greases of different brands.
- c. If your linear guide has rust prevention specifications, put lubricant inside slide before using.



(2) Handling

- a. Interchangeable slides are installed on a provisional rail when they leave the factory.
 Handle the slide with care during installation to the rail.
- b. Do not disassemble the linear guide unless absolutely necessary. Not only does it allow dust to enter, but it lessens precision.
- c. The slide may move by simply leaning the rail. Make sure that the slide does not disengage from the rail.
- d. Standard end caps are made of plastic.
 Beating it or hitting it against an object may cause damage.

(3) Usage precautions



- a. Make every effort not to allow dust or foreign objects to enter.
- b. Please apply splash guard or bellows to the linear guide to prevent solvents or coolant from adhering when they contain corrosive material.
- c. The temperature where linear guides are used should not exceed 80°C (excluding heat-resistant linear guides). A higher temperature may damage the plastic end cap.
- d. If the user cuts the rail, thoroughly remove burrs and sharp edges on the cut surface.
- e. When hanging upside-down (e.g. the rail is installed upside-down on the ceiling and the slide faces downward), should the end cap be damaged causing the balls or rollers to fall out, the slide may detach from the rail and fall. For such use, take measures including installing safety devices.

(4) Storage



- a. When storing the product, store it in the original packaging. Do not open the package or break the inner packaging unnecessarily. It may cause foreign matter to enter or rusting and may cause deterioration of functions.
- b. A place where the indoor environment is hot and humid is not suitable because it significantly reduces the rust prevention effect. Store in a place with low humidity and little temperature change.
- c. Linear guides may bend if the rail is stored in an inappropriate position. Place it on a suitable surface, and store it in a flat position.

Installation of NSK Linear Guides[™] [No.1 Machine Tools]

We thank you very much for your patronage of NSK linear guides. This manual describes the procedure for handling of NSK Linear Guides and installation in machine tools with the prescribed accuracy.



We recommend two types of NSK linear guides for the machine tools application. One is Roller Guide RA Model that offers high rigidity, highly reliable durability and high impact load carrying capacity. The other is Linear Guide LA Model that has been widely accepted in the field.



NSK Linear Guides are composed of a rail that governs linear motion of slides, and slides containing recirculating rolling elements that allow smooth movement and retain rigidity of a machine's table or saddle.

Note: Be aware that balls of LA Model fall out a ball slide when it is removed from a rail.



In "installation of the linear guide to the machine tool", it is important to take sufficient measurement data during trial installation and install surely.

Before installing linear guides for the first time, we recommend a trial installation to gain experience with the procedure. In this trial installation, carefully measure the accuracy of the mounting surfaces on the machine and the accuracy of the linear guides to clarify the relation with the required table accuracy. This will enable you to judge the required accuracy of the machine base and accuracy grade of linear guides, as well as how and what degree you have to measure related accuracy, so that no problems will arise after the machines are finally put into mass production. When installing linear guides for the first time, carefully follow the procedure in this manual.

Remove burrs and roughness on the machine base mounting surfaces with an oil stone.

Apply machine oil or similar oil with low viscosity to the mounting surface to increase the rust preventive effect.



Highly precise measurements of the machine base are necessary; therefore, appropriate instruments in good condition must be used. Suitable instruments are described next.

The motion of any object can be separated into six "degrees of freedom": three angular movements (pitching, yawing, and rolling) and three linear movements (longitudinal, vertical, and lateral).



Instruments, which are suitable for only specific measurements, must be maintained and used properly.

Most levels utilize bubbles in a fluid, but some are electric and have a digital indicator. Both types can measure angular wobble in pitching and rolling.



A good straightedge and a dial indicator or an electrical micrometer can be used under the ordinarily conditions to measure pitching, yawing, and rolling as well as vertical and lateral movements.



Laser interferometer can read pitching, yawing, and linear movement with high accuracy; however, it is hard to handle and requires much time for the setting.



For the purposes of this manual, the combination of a straightedge and a dial indicator was chosen.

The machine base mounting surfaces are designated here as "A" for the rail bottoms and "B" for the rail sides. The linearity and parallelism of these surfaces are measured in the following manner.



Autocollimators measure angular movement using reflected light, so they can measure pitching and yawing accurately.



To measure the linearity of A1 surface, place a suitable measuring block on one surface and attach a dial indicator to it with its stylus on a straightedge lying parallel to surface A1. Holding the block firmly against surface B1 with both hands, slide the block along surface A1 for a specified step, record the measurement, then repeat the same to the end of the rail.





Then repeat the measurements for A2 surface. When doing this, it is important not to move the straightedge.



For the B2 surface measurement, the same procedure is required. In this case also, the straightedge must not be moved.





The measurements of B1 and B2 surfaces also determine their parallelism.



Parallelism of surface B1 and B2 $x_0 \mu m / y mm$

From the measurements of the A1 and A2 surfaces, determine their parallelism.



Parallelism of surface A1 and A2 $\,$ z_{0} $\,\mu m$ /y mm

To measure the linearity of the B1 surface of the machine base, use an arrangement similar to that for the A surfaces but with the dial indicator stylus against the side of the straightedge.





- 8 -

The accuracy measurement of the linear guide mounting surfaces is now complete. The linear guides should be carefully installed using the following procedure.

NSK linear guides are packed in corrugated cardboard boxes. Generally we pack the linear guides for machine tools as a pair in the shipping container. The linear guides are first wrapped in polyethylene films and placed in their boxes together with an inspection sheet or a certification sheet.

Caps for the rail mounting holes are also included if requested by the customer.





For the P3, P4 and P5 accuracy grades, actual inspection data are listed on the inspection sheets.

NSK Line INSPECT	ar Guides™ ION SHEET		NS 	SK S				int with Mile Constraints Constraints Constraints	897.06 CI	
NSK REF, No. LA3	351800BNC2-**)	K43	. 6	-	Running	parallelium Max			Jen	
Ba	No. II 51-002	_				10		2	ing a	
narany graduitti					illocarted re	-	~		Unite 1	
aaraay gaadasifti baqoostan hama tiabittii	Panalashia Valeo		-	101.5	illoomrod ro	at Gill		0.0 0.0	Unite sy	-
nenny grado/95 basocilan Hama GADER seeling holyt H	Personalities Values	1	1		illusered re 4	1		9.J	Unite sy	
untary grade/FE basection huma datation contine Autor 200 H ristion of bioasting height H	Passilohis Valo SGR 210 8	1	1010 2 -1	10L) 8	Homend re 4	1		8.1 8	Udio 1)	-
anay gade/95 bapoolin hana datta sella keja H tata et touring helpt H theodelit uning willing to	Possilautio Valoo 8988 10 8	1	1000 1 -1	100.) 100.) 8	4	1 -1	;	•	4	
Internet grader/PS Interportion Teams Interted Refer Af California of Honoriting Interfer M California of Honoriting Interfer Refer Af California of Honoriting width VE	Pantioliis Valoo 848 410 8 218 7	1 0	1015 23 -1 -1	1003 1003 1004 1004 1004 1004 1004 1004	Honord ro 4	1 -1	;	95.1 • 10	Unite 1;	
Nepeoden Rems CARES VIENT CARES CARE	Pentinkis Vale 808 410 8 419 7 8/1900	1 0 -9	-4	100.) Ba	4	1 -1 -2		6.0 • h. •	4	
basedon Kana basedon Kana colora colora de la Kalan d'Academia halpe H Malan d'Academia halpe H Malan d'Academia halpe H Mill Via del Via della del Via della del Via della del via della della della colora establica di so di la colorazione della della colorazione della della della della colorazione della della della colorazione della della della colorazione della della della della colorazione della della della della della colorazione della della della della della colorazione della d	Penticitie Valeo 890 8 8 8 8 8 8 8 7 8/1800 8/1800 8/1800	1 0 -9	-1 -1 -1	6 (01) 6 (01) 8	4	-1		9.1 9 h. 9	4	
Anterior grader? Lascottes hans celles celles termine help H State H	Penniuchio Valeo 840 8 8 8 7 8/1800 8/1800 8/1800 8/1800 8/1800	1 0 -0 4		6	4	-1 -1 -1 -1 -1 -1 -1 -1 -1 -1 -1 -1 -1 -		8.0 9 B. 9	4	
namer enderfö basedia hans additi datta basedia och hans additi basedia additi addi add	Pussbuchis Velue 800 410 6 418 7 8/180 8/1800 8/1800 8/1800 8/1800 8/1800 8/1800 8/1800	-0 -0 4 -0	8418 82 -1 -3 -3 -3 -3 -3 -3 -3 -3 -3 -3 -3 -3 -3	101) ba		-1 -1 -2 -2 -3 -2 -2 -2 -2 -2 -2 -2 -2 -2 -2 -2 -2 -2		0.0 0 D. 0 0 0 0 0	4	

Remove the wrapping and look for the reference and production numbers on the sides of the rails and slides.



Both rails and slides are marked with groove mark that designate the datum surface.



The two rails look similar but one of them is the reference rail that has controlled dimensional variation on the slide datum faces against that of the rail. If other slides are installed against the table's reference side surface, the table will be skewed as shown by the alternate long and short dash lines in the figure. Generally, no reference side face is provided on the table for the other rail; therefore, the slide face variation is not controlled so closely. This rail is called the "adjusting side rail."



The reference rail is distinguished from the adjusting side rail by the letters KL following the production number on the rail side.



Linear Guides have been coated with rust preventive oil, so wipe it off thoroughly.



Place a linear guide on the machine base as it is ready for installation.

Confirm that the rail is reference side rail, and the datum surface of the rail comes to face to face with the datum surface of the machine base. Keep the slides on the rail, and carefully place the rail on the machine base on its mounting surface. Loosely tighten the rail fixing bolts so that the rail's bottom is firmly against the base.

At this time, press the rail from sideways to make the rail tightly contact to the mounting surface of the machine base. Apply tightening torque to the bolt in Table 1 on page 11 when tightening a shoulder plate. If the rigidity of the mounting surface is low, adjustment of the torque is required.





For final tightening of the bolts to secure the rail, tighten the bolt on either end of the rail first, then proceed to other end. Apply tightening torque to the bolt in Table 1. If the datum surface is on the left side as shown in figure, tighten the bolt at the farthest end first, then proceed to the near end. This way creates a bolt rotating force that presses the rail against the shoulder.

Far side

Near side

Direction of tightening

Table1Tightening torque of bolts (Material: Chromium molybdenum steel) Unit : N·m

Bolt size	Tightening torque	Bolt size	Tightening torque
M2.3	0.38	M10	43
M2.5	0.58	M12	76
M3	1.06	M14	122
M4	2.5	M16	196
M5	5.1	M18	265
M6	8.6	M22	520
M8	22		

After installing the linear guides as explained above, mount a steel plate on the pair of slides on one rail and measure the pitching by following the same procedure used for inspecting the machine base reference surfaces.

Measure the yawing in the same way and compare the data with that obtained for the machine base reference surfaces to find the variation caused by the installation of the guides.





Linear guides will deform to fit the contour of the machine base; i.e., they will become concave if the machine base is concave. If it is not attained, use care when taking measurements since vibration of the machine or floor will cause trouble.

Finally, install the table and check the accuracy of the entire assembly.

The check can be done with the saddle or interim table.

The graph on the right is image of angular movement. (To measure rolling value, pitching value must be subtracted.)

First, arrange the slides so that locations match to their mounting section of the table. Carefully place the table on the slides. Loosely tighten all bolts.

While pressing the table from sideways, further tighten the bolts which secure the slides on the reference side, so the table shoulder and the slide's mounting datum surface are sufficiently tightly pressed.

Then, further tighten the bolts for slides on the adjusting side rail.

Move the table by hand to confirm that there is no abnormality such as excessive friction force during stroking. (This confirms that the correct installation steps were taken.)

Finally, tighten all bolts with the specified torque.

The linearity of the completed assembly should be better than that for individual slides; however, this depends on the rigidity of the machine and the installing accuracy.

The measurements obtained are important characteristics of each machine built, and are essential data for your installation work instruction at the mass production.

If you removed rust preventive oil or grease from surfaces of the linear guides when installing linear guides, we recommend supplying a rust preventive oil or grease on rail surfaces after installation.



x : Straightness of mounting surface x1 : Straightness of the table







The installation of linear guides is easy if the instructions in this manual are followed carefully. As the final part of the manual, this section describes the allowable tolerances for installation in order to maximize the performance of NSK linear guides. The allowable errors, which are shown below, consist of the error in parallelism (e_1) and error in height (e_2) of the two rails.



Permissible values of mounting error for the RA Model

Unit: µm

Value	Drolood	Model No.									
value	Preioad	RA15	RA20	RA25	RA30	RA35	RA45	RA55	RA65		
Permissible values for parallelism error of two rails <i>e</i> ₁	Z3, ZH	5	7	9	11	13	17	19	30		
Permissible values for height error of two rails e_2	Z3, ZH			1	50 µm /	500 mr	n				

Permissible values of	mounting	g error fo	r the LA I	Vodel		Unit: µ
Value	Drolood			Mode	el No.	
value	Preioad		1.1.0.0			

Value	1 I Olouu	LA25	LA30	LA35	LA45	LA55	LA65
Permissible values for	Z3	15	17	20	25	30	40
parallelism error of two rails e1	Z4	13	15	17	20	25	30
Permissible values for height error of two rails e_2	Z3, Z4			185 µm /	500 mm		

Permissible values of mounting error for the NH Model

Unit: µm

Value	Drolood	Model No.									
value	Preload	NH15	NH20	NH25	NH30	NH35	NH45	NH55	NH65		
Permissible values for	Z1, ZZ	18	20	25	30	35	45	55	70		
parallelism error of two rails e_1	Z3, ZH	13	15	20	25	30	40	45	60		
Permissible values for	Z1, ZZ,				20	E00 man					
height error of two rails e2	Z3, ZH			Ċ	30 μm /	500 mi	T1				

Naturally, errors should be as small as possible to achieve the highest performance and reliability of your products. For allowable installation error, refer to the catalog "Precision Machine Components".

The procedure for installing linear guides is not too difficult, but care is required. In case of an improper installation, it is necessary to remove them and check all the related parts; however, we hope this will never be necessary. Many machine tool builders install linear guides regularly with no difficulty by following the procedure that is modified to meet their way of checkings based on this manual.

For assistance or more information, please contact an NSK branch office.

Assembly and Installation of NSK Linear Guides[™] [No.2: General Industrial Machines]

Thank you for choosing NSK linear guides. This manual briefly describes the recommended handling and installation of NSK linear guides for general industrial use.

There are two ways installing the linear guides into general industrial machines. One of them provides a datum shoulder on the mounting base of the machine for accurate horizontal alignment the same as the way for machine tools, while the other is not required a datum shoulder. Refer to "No.1 Machine Tools" for installation procedure that requires a datum shoulder for accurate horizontal alignment. The installation procedure described in this manual assumes that the datum shoulder is not required for horizontal alignment.

For general industrial machines, wide variations of model are available, mainly NH, NS, and LW models that have high self-aligning capability and the capacity to absorb errors in installation.

The products of interchangeable rails and ball slides are standardized for easy addition of ball slides and their replacement, and that support short-term delivery.



For interchangeable NH, NS, and LW models linear guides, interchangeable ball slides and rails are possible and they are stocked separately. The ball slides are mounted on plastic provisional rails that allows for easy transfer of the ball slide to and from the steel rail.



The ball slides are designed with retainers to prevent the balls from falling out when they are removed from the rail. However, NSK recommends that the ball slide should be stored on a provisional rail prior to installation to prevent contamination from dust and other foreign objects.

The following is a description of how the ball slide should be removed from and replaced on the linear guide rail.

The ball slide is held on the provisional rail using a band. The band should catch the bottom channel in the provisional rail and secure the ball slide.



When transferring the ball slide from the provisional rail onto the rail, or vice versa, butt the provisional rail up against the rail and slide the ball slide directly from one onto the other. It is a good idea to secure the ball slide onto the provisional rail with a band after removal from the rail.





The following section describes how to install the linear guides on the machine.

Ball slides and rails are supplied separately. Each is wrapped in polyethylene film, and packed in a container. The label which guarantees each product adheres to it.



Caps for rail mounting holes are available upon request.



The rail is always shipped with rust preventive oil, which should be wiped off before applying grease to the rail. Ball slides are pre-packed with NSK standard grease, so no cleaning is required prior to installation.

Now the linear guide is ready for installation. Put it on a mounting surface.

Temporarily tighten its mounting bolts lightly so that the rail's bottom is firmly against the base.

Then tighten the bolts firmly with torque wrench to the specified torque starting from the one end.





f

When installing a linear guide rail on a flat surface the same as this case, the rail tends to be slightly bent in the shape of S letter if the bolts are tightened indiscriminately starting near the middle because of friction at the seat of bolt head. NSK recommends that the bolts be tightened starting at one end with the wrench as shown in the above figure.

The rail that has been tightened can now be used as a reference rail. Using a vernier calipers or other accurate tool, measure the distance between the two rails, and adjust each end until they are the same. Tighten a bolt snugly at each end of the rail.





Place the table on the linear guides. Tighten the slides on the reference side rail and one slide on the adjustment side rail with the specified torque. Leave the rest of the slide on the adjusting side rail loosely tightened.

While moving the table with each pitch of the bolt for rail: With the specified torque, tighten the rail mounting bolt which is located immediately adjacent to the slide on the adjusting side rail that had been firmly tightened. Take this procedure from one end to the other.

Return the table to the original position once. Then tighten the rest of the slides on the adjusting side to the specified torque. By the same procedure as before, tighten the rest of the rail mounting bolts to the specified torque. Move the table to check any abnormality such as large friction force.

We recommend supplying a rust preventive oil or grease on rail surfaces after installation.

As described above, installation of the linear guides is not difficult work if you carefully follow the above procedure.

However, objective of the preceding procedure is only for an assembly of the table that moves smoothly. If you need to control motion accuracy of the table (straightness), it requires to add the following procedure.

When bolting the first rail on the machine base, align it straight using a straightedge and a dial indicator.

Bolt on the rail at the both ends lightly, and position a straightedge beside it. Set the straightedge parallel to the rail measuring distance A1 and A2 by a dial indicator.

Using the straightedge as the reference, with a dial indicator, check parallelism with the rail, and adjust the rail. Then tighten the bolts. Ensure that the straight edge does not move while the bolts are being tightened. This procedure should be carried out starting from one end of the rail to the other end. The straightness of installation should be adjusted to the required straightness of the machine. Finally tighten all bolts with specified torque and recheck the straightness with a dial indicator.

Position the dial indicator on two ball slides on the reference rail as shown in the diagram. Tighten bolts of the adjusting side rail sequentially from the one end while noting the reading of the dial indicator.

We recommend supplying a rust preventive oil or grease on rail surfaces after installation.

There is another way for installation of adjusting side rail; Based on the straight edge which is used for reference side rail installation.





In order to maintain stable production of the tables, we recommend to install the linear guides while checking the alignment accuracy quantitatively even smooth operation is the least requirement.

As the final part of the manual, this section describes the allowable tolerances for installation in order to maximize the performance of NSK linear guides.

We recommend that the mounting errors e_1 and e_2 do not exceed the values shown in the table below.



Permissible values of mounting error for the NH Model

Unit: µm

	Drolood				Mode	el No.			
value	Preioad	NH15	NH20	NH25	NH30	NH35	NH45	NH55	NH65
Permissible values	Z0, ZT	22	30	40	45	55	65	80	110
for parallelism error	Z1, ZZ	18	20	25	30	35	45	55	70
of two rails e ₁	Z3, ZH	13	15	20	25	30	40	45	60
Permissible values	Z0, ZT				375 µm /	500 mm			
two rails e2	Z1, ZZ, Z3, ZH				330 µm /	500 mm			

Permissible values of mounting error for the NS Model

Model No. Preload Value NS15 NS20 NS25 NS30 NS35 20 22 30 35 40 Z0, ZT Permissible values for parallelism error Z1, ZZ 15 17 20 25 30 of two rails e1 Z3, ZH 12 15 15 20 25 Z0, ZT 375 µm / 500 mm Permissible values for height error of Z1, ZZ, Z3, ZH 330 µm / 500 mm two rails e2

Permissible values of mounting error for the LW Model

Unit: µm

Unit: µm

Value	Droload			Model No.		
value	Fleioau	LW17	LW21	LW27	LW35	LW50
Permissible values	Z0, ZT	20	20	25	38	50
of two rails e ₁	Z1, ZZ	9	9	13	23	34
Permissible values	Z0, ZT		1(00 µm / 500 mi	n	
two rails e2	Z1, ZZ		4	5 µm / 500 mn	n	

Naturally, errors should be as small as possible to achieve the highest performance and reliability of your products. For explanations of allowable installation, refer to the catalog "Precision Machine Components".

The procedure for installing linear guides is not too difficult, but care is required. In case of an improper installation, it is necessary to remove them and check all the related parts; however, we hope this will never be necessary.

Please contact your local NSK branch office for any questions regarding the installation of NSK linear guides.



Worldwide Sales Offices

P: Phone 💠: Head Office

NSK LTD. HEADQUARTERS, TOKYO J	APAN	Indonesia:		Turkey:	
NDUSTRIAL MACHINERY BUSINESS DIVISION-HEADQUARTERS	P: +81-3-3779-7227	PT. NSK INDONESIA		NSK RULMANLARI ORTA DOGU TIC.	LTD. STI.
AUTOMOTIVE BUSINESS DIVISION-HEADQUARTERS	P: +81-3-3779-7189	JAKARTA	P: +62-21-252-3458	STANBUL	P: +90-216-5000-675
Africa		Korea:		United Arab Emirates:	
South Africa:		NSK KOREA CO., LTD.		NSK BEARINGS GULF TRADING CO.	
NSK SOUTH AFRICA (PTY) LTD		SEOUL	P: +82-2-3287-0300	DUBA	P: +971-(0)4-804-8200
SANDTON	P: +27-011-458-3600	Malaysia:	_	North and South America	
Aisia and Oceania		NSK BEARINGS (MALAYSIA) SDN BHI). D 00.0 7000 0050	United Sates of America:	
Australia:		SHAH ALAM 😥	P: +60-3-7803-8859	NSK AMERICAS, INC. (AMERICAN HE	ADQUARTERS)
NSK AUSTRALIA PTY, LTD,		PRA	P: +60-4-3902275	ANN ARBOR	P: +1-734-913-7500
MELBOURNE 🚖	P: +61-3-9765-4400	JOHOR BAHRU	P: +60-7-3546290	NSK CORPORATION	
SYDNEY	P: +61-2-9839-2300	IPOH Bhilianin an	P: +60-5-2555000	ANN ARBOR	P: +1-734-913-7500
BRISBANE	P: +61-7-3347-2600	Philippines:		NSK PRECISION AMERICA, INC.	
PERTH	P: +61-8-9256-5000	MANUA	Di 162 0 802 0E42	FRANKLIN 🕸	P: +1-317-738-5000
New Zealand:		Singapore	F. +03-2-093-9343	SAN JOSE	P: +1-408-944-9400
NSK NEW ZEALAND LTD.		NEK INTERNATIONAL (SINCAROPE)	TELTO	NSK LATIN AMERICA, INC.	
AUCKLAND	P: +64-9-276-4992	SINGADODE	D: 165 6406 9000	MIAMI	P: +1-305-477-0605
China:		Theiland	P. +03-0480-0000	Canada:	
NSK (SHANGHAI) TRADING CO., LTD.		NSK READINGS (THAILAND) CO. LTD		NSK CANADA INC.	
JIANGSU ☆	P: +86-512-5796-3000	BANGKOK	D: 166 0000 0555	TORONTO 😭	P: +1-888-603-7667
NSK (CHINA) INVESTMENT CO., LTD.		Vietnom	F. +00-2320-2333	MONTREAL	P: +1-514-633-1220
JIANGSU 🛧	P: +86-512-5796-3000	NEK VIETNAM COLUTD		Argentina:	
BEIJING	P: +86-10-6590-8161	HANOL	D: . 94 04 2055 0150	NSK ARGENTINA SRL	
TIAN JIN	P: +86-22-8319-5030	NSK REPRESENTATIVE OFFICE	1.404 24 0355 0155	BUENOS AIRES	P: +54-11-4/04-5100
CHANGCHUN	P: +86-431-8898-8682	HO CHI MINH CITY	D: 184 28 3822 7007	Brazil:	
SHENYANG	P: +86-24-2550-5017	-	1. +04-20-3022-1301	NSK BRASIL LTDA.	
DALIAN	P: +86-411-8800-8168	Europe		SUZANO 🌣	P: +55-11-4744-2500
NANJING	P: +86-25-8472-6671	United Kingdom:		JOINVILLE	P: +55-47-3422-2239
FUZHOU	P: +86-591-8380-1030	NSK EUROPE LTD. (EUROPEAN HEAD	DQUARTERS)	Peru:	
WUHAN	P: +86-27-8556-9630	MAIDENHEAD	P: +44-1628-509-800	NSK PERU S.A.C.	
QINGDAO	P: +86-532-5568-3877	NSK UK LID.		LIMA	P: +51-493-4385
GUANGZHOU	P: +86-20-3817-7800	NEWARK	P: +44-1636-605-123	Mexico:	
CHANGSHA	P: +86-731-8571-3100	France:		NSK RODAMIENTOS MEXICANA, S.A.	DE C.V.
LUOYANG	P: +86-379-6069-6188	NSK FRANCE S.A.S.		SILAO, GUANAJUATO	P: +52-4/2-500-9500
XIAN	P: +86-29-8765-1896	PARIS	P: +33-1-30-57-39-39		
CHONGQING	P: +86-23-6806-5310	Germany:			
CHENGDU	P: +86-28-8528-3680	NSK DEUTSCHLAND GMBH	D 10 0100 1010		
NSK CHINA SALES CO., LTD.		DUSSELDORF ST	P: +49-2102-4810		
JIANGSU ☆	P: +86-512-5796-3000	STUTIGART	P: +49-711-79082-0		
NSK HONG KONG LTD.		WOLFSBURG	P: +49-5361-27647-10		
HONG KONG 🌣	P: +852-2739-9933	Italy:			
SHENZHEN	P: +86-755-25904886	NSK ITALIA S.P.A.	Di 120.000 5101		
Taiwan:		Netherlander	F. +39-299-3191		
TAIWAN NSK PRECISION CO., LTD.		NEW EUROPEAN DISTRIBUTION CEN			
TAIPEI ☆	P: +886-2-2772-3355	TIL DUDO	D01 10 4647647		
TAICHUNG	P: +886-4-2708-3393	Belend	P. +31-13-4647647		
TAINAN	P: +886-6-215-6058	NSK DOLSKA SP Z O O			
India:		WARSAW	P: +48-22-645-1525		
NSK BEARINGS INDIA PRIVATE LTD.		Sosin	1.740-22-040-1020		
CHENNAI 😭	P: +91-44-28479600	NSK SPAIN S A			
GUHGAON	P: +91-124-4838000	BARCELONA	P: +34-93-289-2763		<as 2022="" july="" of=""></as>
MUMBA	P: +91-22-28387787	DANGELONA	1. 404 30 205-2703	For the latest information alternation	to the NEK webit-
JAMSHEDPUR	P: +91-657-2421144			For the latest information, please refe	I to the NSK website.
					www.nsk.com

Every care has been taken to ensure the accuracy of data in this publication, but NSK Ltd. accepts no liability for any loss or damage incurred from errors or omissions. As we pursue continuous improvement, all content (text, images, product appearances, specifications, etc.) contained in this publication is subject to change without notice. Unauthorized copying and/or use of the contents of this publication is strictly prohibited. Please investigate and follow the latest product export laws, regulations, and permit procedures when exporting to other countries.

For more information about NSK products, please contact:

