

Thank you for using our product.
Please read the following notes carefully before using this software.

- 1. By performing the following operations on terminal screen, it may cause the data sent to the driver to be corrupted, or the application may be terminated unexpectedly, so
- DO NOT enter a command when the cursor is NOT at the end of the last letter.
- DO NOT delete the command entered with the Delete key.
- DO NOT use undo/cut/copy/paste.
2. Even if you press the 'R' key while performing adjustment ('/AJ' option) on the terminal screen, you cannot reset the settings to the factory default values. If you want to reset to the factory defaults, press the Backspace key to finish the adjustment and execute the reset to the factory defaults ('/RS' option).
3. If you delete the setting value of a parameter or command on the parameter edit screen and confirm the value by pressing the Enter key or moving the cursor while the setting value is empty, the setting value will be treated as '0' and the operation will be as follows.

<For parameters>
When the parameter setting value is deleted, the parameter is set to '0'.
Ex) When the set value of SG parameter is deleted
Send 'SG0' from EDD Megaterm to the drive unit and set the SG setting value to '0'.
<For commands>
When the command setting value is deleted, the command will be executed with the command value '0'.
Ex) When deleting the setting value of the AD command
Send 'AD0' from EDD Megaterm to the drive unit.
*Please note that the motor may operate when the servo is ON.

- Note:
1. All NSK product and service names listed are trademarks or registered trademarks of NSK Ltd.
2. Other product and company names used are trade names, trademarks, or registered trademarks of their respective companies.
3. The reproduction, copy, or alteration of information contained within without permission from NSK Ltd. is prohibited.
4. The information contained within is subject to change without advance notice.