

Thank you for using our product.

Please read the following notes carefully before using this software.

1. System requirements

It is strongly recommended to use EDD Megaterm with the following system.

OS*1

Windows English version
Windows7 Home/Professional/Enterprise/Ultimate
Windows10 Home/Pro/Enterprise
*1 With Internet Explorer 11 or above

With the following system fonts:
Courier New, Arial

CPU

1GHz or above 32-bit (x86) or 64-bit (x64) CPU

Memory

1GB or above (32-bit) or 2GB or above (64-bit)

HDD

16GB (32-bit) or 20GB (64-bit) or more free space available

Display

800 x 600 (SVGA) or above

Ports

USB

2. Installation

2.1. WinUSB

Run WinUSB from [%Install%WinUSB%WinUSB.vbs] and install device driver.

2.2. EDD Megaterm

Run setup from [%Install%EDDmegaterm%setup.exe] and install the EDD Megaterm application.

* If you are already using the EDD Megaterm, please uninstall the EDD Megaterm you are using and then reinstall the latest version.

3. How to Use EDD Megaterm

After installation completes, please see "Online Help".

Note:

1. All NSK product and service names listed are trademarks or registered trademarks of NSK Ltd.
2. Other product and company names used are trade names, trademarks, or registered trademarks of their respective companies.
3. The reproduction, copy, or alteration of information contained within without permission from NSK Ltd. is prohibited.
4. The information contained within is subject to change without advance notice.